



Send, from TIUD to GCo and GCT, a setup message for the call Establish a gate at NEDT upon receiving sety nessay from GLT Establish a gate at NEDo upon receiving the setup nessage from GCo Beid a reserve nossage from TIVo to NEO. ~ 240 Send a reserve nessage from TIUT to NEDT Exchange end- to- end nessage between TIVO and TIV Upon connecting the calling party and the called party, send a commit nessage from TIUs to | ~270 NEO. and from TIUT to NEDT Upon receiving the Commit nessage at NEPo, open the gate at NED. Upon receiving the Commit nessage at NEDTS me gote at NEDT

Calling party goes off-hook and dids a telephone number of the called party TIVo collects the dialed digits ~ 320 TIVO sends a setup nessage to GCO Forward The setup nessage to GCT - 340. Forward the set op nessage to TIU ~ 350 _ 360 If the destination address of the setup nessage matches TIUT, sending to the TIUs a setup acknowledgement necessage Reserve network resources ~370 Send from TIU0 to TIUT an end-to-end king ressage Send from TIUT to TIU0 on end-to-end Ringback nessage 1 390 Upon call acceptance by the called party, send on end-to-end Connect wessage from TIUT to TIU.





F161.5




Figure 6




Figure 7




Figure 8




Figure 9




Figure 10




Figure 11




Figure 12




Figure 13




Figure 14









Figure 15
















Figure 21








Figure 24




Figure 25




Figure 26




Figure 27




Figure 28




Figure 29




Figure 30








Figure 31




Figure 32